


Moulinex

# HF800A12/702

1550W




Moulinex

# HF800A12/702

1550W

MS-4A19078




MS-0A19122




MS-5949035



MS-0A19132




MS-8080017762



MS-8080017763




MS-0698252



MS-0A19001



MS-0A08112



MS-4A19131


MS-0A19135



Moulinex

**HF800A12/702**  
1550W

MS-0A19117



MS-8030000305

MS-0A19114

XF380E12





MS-0A19157

MS-8030000417

MS-7232601568

MS-8080017770

MS-8080017297




MS-8080017769

MS-8080017297



MS-0A19025



MS-8030000307


Moulinex

HF800A12/702  
1550W

# OPTION

XF389010

MS-8030000889




Moulinex

HF800A12/702  
1550W

# OPTION

## XF383110




Moulinex


HF800A12/702  
1550W

# OPTION

XF384B10




MS-8030000889




Moulinex

**HF800A12/702**  
1550W


MS-0A19150




MS-0A19230




MS-0A19242



MS-0A19037




MS-0A19035




MS-0A19166




MS-0A19167



MS-0A19062



MS-0A19061




Moulinex

HF800A12/702  
1550W

# OPTION

XF38AE10





Moulinex

HF800A12/702  
1550W

# OPTION

XF387E10

